

Contractor: Leave this information with the homeowner

Compustat — Designed for Duct Mounting Only



In order for *Compustat* (Skuttle's electronic, weather-sensing humidistat) to monitor indoor relative humidity, it requires direct access to air within the home's ductwork. Therefore, it cannot be effectively mounted on an interior wall; **it must be mounted on the return air ductwork.**

Unlike standard humidistats, *Compustat* provides these attractive benefits:

- **Automatically adjusts a home's relative humidity** via a remote sensor, based on the outdoor temperature and the homeowner's preferred level of comfort.
- **Features set-it-and-forget-it technology** to maintain a constant, comfortable level of humidity throughout the heating season.
- **Continually protects home and furnishings** against the damaging effects of dry or overly-humidified air.
- **Provides extra defense against "sick house" conditions** that cause or aggravate allergies, colds, flu and respiratory ailments.
- **Contains solid-state, UV-resistant components** for safer, more reliable operation.
- **Offers a manual operation option** to allow residents to fine-tune indoor relative humidity.



Skuttle®

Indoor Air Quality Products

101 Margaret Street • Marietta, OH 45750

Phone: 888-SKUTTLE (758-8853) • Fax: 740-373-9565

Email: customerservice@skuttle.com • Web: www.skuttle.com

Due to Skuttle Mfg. Co.'s continuing research, design specifications and components are subject to change without notice.

© 2007, Skuttle Mfg. Co. 00M/HBP • 000-0000-000